

Woodward Governor Digital Modules & Miscellaneous Parts	
Part Number	Description
8200-209	ProTech 203
8200-210	ProTech 203
8200-211	ProTech 203
8200-217	Excel 250
8200-220	SPC (Servo Position Controller)
8200-224	SPC (Servo Position Controller)
8200-225	SPC (Servo Position Controller)
8200-226	SPC (Servo Position Controller)
8200-300	ProTech 203
8200-301	ProTech 203
8200-302	ProTech 203
8200-303	ProTech 203
8200-304	ProTech 203
8200-305	ProTech 203
8200-310	ProTech 203
8200-311	ProTech 203
8200-312	ProTech 203
8200-314	GS/LQ Digital Driver
8200-321	ProTech 203
8200-322	ProTech 203
8200-323	ProTech 203
8200-324	ProTech 203
8200-325	ProTech 203
8200-326	ProTech 203
8200-330	ProTech 203
8200-331	ProTech 203
8200-332	ProTech 203
8220-805	Final Driver
8226-043	OCP (Operator Control Panel)
8230-082	Load share Interface Module

Woodward Governor Digital Modules & Miscellaneous Parts	
Part Number	Description
8230-159	43027 Speed Control with Pressure Control Rack
8230-327	43027 Position Control with Power Supply Rack
8230-388	43027 Speed Control with Power Supply Rack
8230-568	Control Panel
8230-681	43027 Speed, Extaction, & Inlet Pressure Control Rack
8230-682	43027 Operator Control Panel
8230-690	43027 Speed Control with Back Pressure Control
8230-785	43027
8230-791	43027
8230-802	43027
8230-805	Final Driver
8230-815	Final Driver
8230-819	Digital Remote Final Driver
8230-827	Final Driver
8230-855	43027
8230-857	43027
8230-859	43027
8230-863	Digital Remote Final Driver
8230-871	43027
8230-881	43027
8230-883	Digital Remote Final Driver
8230-883	43027
8230-896	Final Driver
8230-898	Final Driver
8230-905	43027

Woodward Governor Digital Modules & Miscellaneous Parts	
Part Number	Description
8230-907	43027
8230-913	43027
8230-916	43027
8230-929	Digital Remote Final Driver
8232-023	Power Supply
8234-066	511
8234-074	501 Chassis
8234-167	501 Chassis
8234-213	NetCon A Chassis
8234-222	Woodward Board/Module
8234-344	511
8234-346	501 Chassis
8234-557	511
8234-875	Excel 250
8234-876	Excel 250
8234-917	Woodward Board/Module
8234-918	Woodward Board/Module
8236-010	Lamp type Operation Indicator
8236-027	Operate Control Panel
8236-032	Operator Control Panel
8236-036	Annunciator Panel
8236-039	Operator Control Panel
8236-040	Programmer, 4.0 511 Display
8236-043	Interface 43027
8236-051	Operate Control Panel
8236-142	Operate Control Panel
8236-144	Light Panel
8236-151	Operate Control Panel
8236-215	Operate Control Panel
8236-243	Panel