

ABB ABB Industry Oy Marine			Document No. 3AFV7019 2000 206	Sheet 7/ 14
Revision A	Date 14.1.2000	Reason for issue User's Manual	Title CARNIVAL VICTORY	Language en

4. Wait until programs of vector control computer have restarted.

BINARY INPUT BOARD UT A335

X2A40, X2A48, X2A52 BINARY INPUT BOARD SCYC 55860

X2A42, X2A50 BINARY OUTPUT BOARD SCYC 55870

X2A36 ANALOG INPUT BOARD SCYC 55840

X2A44 ANALOG INPUT BOARD SCYC 55880

X2A36, X2A46 ANALOG OUTPUT BOARD SCYC 55890

X2A34 CROSS-CONNECTION BOARD SCYC 50025

X2A32 TACHO INPUT BOARD SCYC 55821

1. Open circuit breakers F3.5 and F4 in control cubicle.
2. Check jumpers and switches.
3. Change board.
4. Close circuit breaker F3.5 and F4.
5. Wait until programs of vector control computer have restarted.